

Component key – 1983 to 1984 R80RT and 1981 on R100, R100CS, R100RT, R100RS models

- 1 Starter button and emergency cutout
- 2 Headlight:
 - a Flasher relay
 - b High beam
 - c Low beam
 - d Parking light
 - e Light relay
 - f Ignition/light switch (R100, R100CS)
 - g Contact board with fuses
- 3 Ignition/light switch (R100RS, RT)
- 4 Dip switch, headlight flasher and horn button
- 5 Running light (R100RS, RT)
- 6 6-pin connector (R100RS, RT)
- 7 Front RH indicator
- 8 Voltmeter
- 9 Clock
- 10 Clutch switch
- 11 Front LH indicator
- 12 Left horn
- 13 Right horn (R100RS, RT)
- 14 Front stoplight switch
- 15 Combined instrument:
 - a Speedometer light
 - b Revolution counter light
 - c High beam tell tale
 - d Neutral indicator
 - e Battery charge indicator
 - f Oil pressure light
 - g Indicator repeater
- 16 Rear stoplight switch
- 17 Starter relay
- 18 Ignition coils
- 19 Spark plugs and caps
- 20 Ignition trigger
- 21 Starter motor
- 22 Battery
- 23 Alternator
- 24 Regulator
- 25 Diode board (rectifier)
- 26 6-pin connector
- 27 Oil pressure switch
- 28 Neutral switch
- 29 Rear RH indicator
- 30 Rear light:
 - a Rear and licence plate light
 - b Brake light
- 31 Rear LH indicator
- 32 TCI unit